

Link do produktu: <https://zamep.pl/bebenek-singer-kl2800-p-422.html>



Bębenek Singer KL2800

Cena	14,76 PLN
Czas wysyłki	24 godziny
Numer katalogowy	0000002085

Opis produktu

Bębenek Singer KL2800

pasuje do maszyn do szycia Singer: 1022, 1100, 1247, 1247N, 1263, 1263N, 1280, 1280N, 1288, 1288N, 1482, 1485, 1486, 1488, 1490, 1492, 1730, 1802, 1803, 1812, 1852, 1853, 1862, 1872, 1873, 2102, 2105, 2106, 2108, 2110, 2112, 2114, 2118, 2210, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 247, 247AP, 2502, 2503, 2504, 2515, 2517, 2530, 2543, 257, 2712, 2718, 2722, 2724, 2730, 2732, 2808, 2818, 288, 2950, 30920, 3100, 3101, 3102, 3103, 3105, 3130, 3140, 3270, 3314, 3317, 3343, 353, 354, 358, 4325, 4517, 4522, 4525, 4526, 4528, 4530, 4538, 4552, 4562, 4572, 4610, 4620, 4622, 4624, 4814, 4817, 4818, 4820, 4822, 4824, 4825, 4826, 4828, 4830, 4832, 495, 500K, 5017, 502, 5028, 5040, 5050, 507, 509, 510, 513, 514, 5160, 518, 522, 527, 530, 533, 534, 538, 5405, 5417, 543, 5430, 560, 5605, 5610, 5705, 5710, 57815, 57815C, 57817, 57820, 57820C, 57825, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5830C, 5838, 5910, 5932, 6011, 6012, 6021, 6038, 6100, 6102, 6104, 6105, 6106, 6110, 6112, 6114, 6115, 6116, 6120, 6122, 6124, 6125, 6130, 6136, 6146, 6152, 6156, 6174, 6180, 6184, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6221, 6233, 6500, 6513, 6522, 6528, 6533, 6543, 6544, 6548, 6606, 6610, 6620, 6700 Series, 6705, 7004, 7015, 7021, 7025, 7028, 7029, 7033, 7035, 7100, 7101, 7102, 7104, 7105, 7106, 7108, 7110, 7136, 714, 717 School, 7174, 7184, 719, 7211, 7212, 724, 734, 774, 776, 800, 8002, 8007, 8019, 8100, 8200, 8220, 827, 830, 833, 834, 844, 8500, 8502, 8505, 8518, 8600, 8602, 8605, 8606, 8610, 8614, 8618, 8734, 8774, 9005, 9008, 9010, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9034, 9044, 9110, 9130, 9134, 9210, 93220, 9323, 93234, 9334, 935U, 9408, 9410, 9416, 9420, 9423, 9430, 9432, 9440, 9444, 9500, 9502, 9505, 9518, 9600, 9602, 9605, 9606, 9608, 9610, 9612, 9614, 9618, 964, 966, 968, 972, 974, 9802, 9803, 9805, 9806, 9808, 9810, 9812, 9814, 9816, 9818, 9824, 9828, 9836, 9858, 9936, CG500, CG550, CG590, CM17, CP17, DL17, DX14C, FM17, FM19, FM22, HD102, HD105, HD110