

Link do produktu: <https://zamep.pl/stopka-universalna-singer-lucznik-kl800-szeroka-p-1388.html>



Stopka uniwersalna Singer - Łucznik KL800 szeroka

Cena	10,63 PLN
Numer katalogowy	0000001956
Producent	Brak

Opis produktu

Stopka uniwersalna Singer - Łucznik KL800 szeroka

Pasuje do Singer KL: 237, 241, 247, 252, 257, 263, 288, 290, 328, 337, 338, 360, 362, 413, 413K, 416, 418, 457, 476, 478, 513, 518, 533, 534, 543, 547, 563, 588, 802, 807, 809, 813, 814, 818, 822, 824, 827, 833, 834, 838, 844, 1021, 1022, 1482, 1485, 1486, 1488, 1490, 1492, 1872, 2001, 2102, 2105, 2106, 2108, 2110, 2112, 2114, 2118, 2210, 2302, 2303, 2304, 2315, 2330, 2404, 2440, 2502, 2503, 2504, 2505, 2515, 2517, 2530, 2543, 2732, 3101, 3102, 3103, 3105, 3270, 3314, 3317, 3343, 4325, 4525, 4528, 4530, 4552, 4622, 4830, 5017, 5028, 5040, 5050, 5417C, 5430, 5430C, 5502, 5504, 5505, 5508, 5522, 5524, 5525, 5528, 5705, 5710, 57817, 57820, 57825, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5828, 5830, 5838, 5932, 6100, 6102, 6104, 6105, 6106, 6110, 6120, 6130, 6136, 6146, 6152, 6156, 6174, 6184, 6210, 6211, 6212, 6214, 6215, 6217, 6221, 6233, 6234, 6235, 6305, 6310, 6314, 6318, 6408, 6412, 6416, 6423, 6620, 7028, 7037, 7136, 7146, 7184, 7186, 7211, 7212, 8734, 9005, 9008, 9010, 9022, 9110, 9113, 9117, 9124, 9134, 9323, 9410, 9420, 9423, 9432, 9444, 9850, 9852, 9855, 9858, 6860, 9867, 9876, CG500, CG550, CG590, CM17, DX14, FM17, FM22, HD102, HD105, HD110 & SM14.