

Link do produktu: <https://zamep.pl/zestaw-25-szt-szpulek-plastik-do-maszyny-singer-p-749.html>



Zestaw 25 szt szpulek plastik. do maszyny Singer

Cena	46,13 PLN
Czas wysyłki	24 godziny
Numer katalogowy	0000000734

Opis produktu

Zestaw 25 szt szpulek plastikowych do maszyny do szycia w pudełku
Pasuje do maszyn:

- maszyna do szycia Łucznik seria KL800
- maszyna do szycia Singer modele: 101, 1019, 1021, 1022, 1025, 1027, 1200, 1247, 1247N, 1263, 1263N, 1280, 1280N, 1288, 1288N, 1482, 1485, 1486, 1488, 1490, 1492, 1730, 1802, 1803, 1812, 185, 1852, 1853, 1862, 1872, 1873, 192, 201, 2102, 2105, 2106, 2108, 2110, 2112, 2114, 2118, 2210, 2300, 2302, 2303, 2304, 2315, 2330, 2404, 241, 242, 2430, 2440, 247, 247AP, 248, 249, 2500, 2502, 2503, 2504, 2505, 2515, 2517, 252, 2530, 2543, 257, 258, 259, 2601, 2602, 2603, 2604, 2605, 2615, 2616, 2628, 263, 2630, 2643, 2712, 2718, 2722, 2724, 2730, 2732, 2808, 2818, 285, 288, 292, 2950, 3100, 3101, 3102, 3103, 3105, 3130, 3140, 3270, 327, 327K, 328, 328K, 329, 3314, 3317, 3343, 337, 338, 347K, 348, 348K, 353, 354, 358, 360, 362, 367, 368, 401, 403, 404, 413, 413K, 413K13, 416, 417, 418, 418K Stylist, 4325, 4522, 4525, 4526, 4528, 4530, 4538, 4552, 4562, 457, 457K, 4572, 4610, 4617, 4620, 4622, 4624, 466, 466K, 476 Stylist, 476K Stylist, 477, 477K, 478, 4814, 4825, 4828, 4830, 4832, 495, 500, 5017, 502, 5028, 503, 503A, 5040, 5050, 507, 509, 513, 514, 5160, 518, 522, 527, 533, 534, 538, 5417, 5430, 543, 547, 560, 5605, 5610, 563, 5705, 5710, 57815, 57817, 57820, 57825, 5802, 5805, 5806, 5808, 5810, 5812, 5814, 5816, 5817, 5818, 5820, 5825, 5830, 5838, 588, 5910, 5932, 6010, 6011, 6012, 6017, 6021, 6038, 6102, 6104, 6105, 6106, 6110, 6112, 6114, 6115, 6116, 6120, 6124, 6125, 6126, 6130, 6136, 6146, 6152, 6156, 6174, 6184, 6201, 6202, 6211, 6212, 6214, 6215, 6217, 6221, 6233, 631, 6513, 6522, 6528, 6533, 6543, 6544, 6548, 66, 6606, 6610, 6620, 66-6, 6700 Series, 6705, 6800, 7004, 7015, 7021, 7025, 7028, 7029, 7033, 7035, 7100 Series, 7101, 7102, 7104, 7105, 7106, 7108, 7110, 7136, 714, 7146, 717E, 717 School, 7174, 7184, 7186, 719, 7211, 7212, 724, 734, 774, 776, 800, 8002, 8007, 8019, 8100, 8200, 8220, 833, 834, 844, 8500, 860 Srs, 8600, 8614, 8734, 8774, 8834, 9005, 9008, 9010, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9034, 9044, 9110, 9130, 9133, 9134, 9137, 9210, 9240, 93220, 9323, 93234, 9334, 935U, 9408, 9408N304, 9410, 9416, 9420, 9423, 9430, 9432, 9444, 9500, 9502, 9505, 9518, 9600, 9602, 9605, 9606, 9608, 9610, 9612, 9614, 9618, 964, 966, 968, 972, 974, 9802, 9803, 9805, 9806, 9808, 9810, 9812, 9814, 9816, 9818, 9824, 9828, 9832, 9836, 99, 9936, CG500, CG550, CG590, CM17, CP17, DL17, DX14, DX-14C, FM17, FM19, FM22, HD102, HD102, HD110, SM14